

GE Oil & Gas

# Masoneilan\* SVI\* FF Function Blocks

## Instruction Manual (Rev B)



## About this Guide

This instruction manual applies to the following instruments and approved software:

- SVI FF
  - with firmware version 1.0.0.1 or higher
  - with ValVue\* version 3.0
  - with handheld communicator with DD published for SVI FF

The information in this manual is subject to change without prior notice.

The information contained in this manual, in whole or part, shall not be transcribed or copied without GE Oil & Gas' written permission.

In no case does this manual guarantee the merchantability of the positioner or the software or its adaptability to a specific client needs.

Please report any errors or questions about the information in this manual to your local supplier or visit [www.geoilandgas.com/valves](http://www.geoilandgas.com/valves).

## DISCLAIMER

**THESE INSTRUCTIONS PROVIDE THE CUSTOMER/OPERATOR WITH IMPORTANT PROJECT-SPECIFIC REFERENCE INFORMATION IN ADDITION TO THE CUSTOMER/OPERATOR'S NORMAL OPERATION AND MAINTENANCE PROCEDURES. SINCE OPERATION AND MAINTENANCE PHILOSOPHIES VARY, GE (GENERAL ELECTRIC COMPANY AND ITS SUBSIDIARIES AND AFFILIATES) DOES NOT ATTEMPT TO DICTATE SPECIFIC PROCEDURES, BUT TO PROVIDE BASIC LIMITATIONS AND REQUIREMENTS CREATED BY THE TYPE OF EQUIPMENT PROVIDED.**

**THESE INSTRUCTIONS ASSUME THAT OPERATORS ALREADY HAVE A GENERAL UNDERSTANDING OF THE REQUIREMENTS FOR SAFE OPERATION OF MECHANICAL AND ELECTRICAL EQUIPMENT IN POTENTIALLY HAZARDOUS ENVIRONMENTS. THEREFORE, THESE INSTRUCTIONS SHOULD BE INTERPRETED AND APPLIED IN CONJUNCTION WITH THE SAFETY RULES AND REGULATIONS APPLICABLE AT THE SITE AND THE PARTICULAR REQUIREMENTS FOR OPERATION OF OTHER EQUIPMENT AT THE SITE.**

**THESE INSTRUCTIONS DO NOT PURPORT TO COVER ALL DETAILS OR VARIATIONS IN EQUIPMENT NOR TO PROVIDE FOR EVERY POSSIBLE CONTINGENCY TO BE MET IN CONNECTION WITH INSTALLATION, OPERATION OR MAINTENANCE. SHOULD FURTHER INFORMATION BE DESIRED OR SHOULD PARTICULAR PROBLEMS ARISE WHICH ARE NOT COVERED SUFFICIENTLY FOR THE CUSTOMER/OPERATOR'S PURPOSES THE MATTER SHOULD BE REFERRED TO GE.**

**THE RIGHTS, OBLIGATIONS AND LIABILITIES OF GE AND THE CUSTOMER/OPERATOR ARE STRICTLY LIMITED TO THOSE EXPRESSLY PROVIDED IN THE CONTRACT RELATING TO THE SUPPLY OF THE EQUIPMENT. NO ADDITIONAL REPRESENTATIONS OR WARRANTIES BY GE REGARDING THE EQUIPMENT OR ITS USE ARE GIVEN OR IMPLIED BY THE ISSUE OF THESE INSTRUCTIONS.**

**THESE INSTRUCTIONS CONTAIN PROPRIETARY INFORMATION OF GE, AND ARE FURNISHED TO THE CUSTOMER/OPERATOR SOLELY TO ASSIST IN THE INSTALLATION, TESTING, OPERATION, AND/OR MAINTENANCE OF THE EQUIPMENT DESCRIBED. THIS DOCUMENT SHALL NOT BE REPRODUCED IN WHOLE OR IN PART NOR SHALL ITS CONTENTS BE DISCLOSED TO ANY THIRD PARTY WITHOUT THE WRITTEN APPROVAL OF GE.**

## Copyright

\* Masoneilan, SVI, and ValVue are registered trademarks of the General Electric Company. FOUNDATION Fieldbus is a trademark of the FOUNDATION Fieldbus organization. Other company names and product names used in this document are the registered trademarks or trademarks of their respective owners. All information contained herein is believed to be accurate at the time of publication and is subject to change without notice.

Copyright 2014 by GE Oil & Gas. All rights reserved. PN 720031290-779-0000 Rev. B

# Contents

1. Introduction and Safety Information .....	7
Introduction.....	7
Safety Information.....	7
Safety Symbols.....	8
SVI FF Product Safety .....	8
2. AO Function Block .....	11
General.....	11
ModesMasoneilan SVI FF Function Blocks Instruction Manual.....	12
Forward Path.....	12
Fault State .....	13
Backward Path .....	13
IO_OPTS and STATUS_OPTS .....	14
Mode Shedding on Computer Failure.....	15
Initialization at Start.....	16
Alarm Processing.....	17
Channel Parameter Applications.....	17
Minimal Configuration.....	17
AO Block Access.....	18
3. PID Function Block .....	19
General.....	19
Modes.....	20
Input Processing .....	21
Setpoint (SP) Limiters.....	21
PID Computation.....	21
Direction of Control Action.....	23
Control Action Bypass .....	23
Feed-forward.....	24
External-output Tracking (LO).....	24
Measured-value Tracking.....	25
CONTROL_OPTS.....	25
Initialization and Manual Fallback (IMan).....	26
STATUS_OPTS.....	26
Auto Fallback.....	27
Mode Shedding on Computer Failure.....	27
Alarms.....	28
Block Alarm (BLOCK_ALM).....	29
Process Alarms.....	29
PID Block Access.....	30
4. Analog Input .....	33
Overview.....	33
Schematic.....	33

Description.....	34
Channel Parameter Applications .....	34
Supported Modes .....	35
Alarm Types.....	35
Mode Handling.....	35
Status Handling.....	36
Initialization .....	36
Minimum Configuration.....	36
Analog Input Block Access .....	37
5. Control Selector .....	39
Overview .....	39
Schematic.....	40
Description.....	40
Supported Modes .....	41
Alarm Types.....	41
Mode Handling.....	41
Status Handling .....	41
Initialization .....	41
BLOCK_ERR_DESC_1 Parameter .....	42
Control Selector Block Access .....	43
6. OS Function Block .....	45
General .....	45
Modes.....	46
Output Processing.....	46
Backward Path (BKCAL_OUT).....	48
OS Block Access .....	48
7. Multiple Analog Input Function Block (MAI) .....	49
Overview .....	49
Schematic.....	49
Usage .....	49
Supported Modes .....	50
Alarm Types.....	50
Mode Handling.....	50
Status Handling .....	50
Initialization .....	50
Multiple Analog Input Function Block Access.....	51
8. Input Selector (IS) Function Block .....	53
General .....	53

Function Supported.....	54
Supported Modes.....	55
Alarm Types.....	55
Mode Handling.....	55
Status Handling.....	55
Initialization.....	55
Power Failure Recovery.....	55
Minimum Configuration.....	56
IS Block Access.....	56
9. Discrete Output.....	57
Overview.....	57
Schematic.....	57
Description.....	58
Channel Parameter Applications.....	58
Supported Modes.....	59
Alarm Types.....	59
Mode Handling.....	59
Status Handling.....	59
Initialization.....	59
Fault State Recovery.....	59
Bad to Good Output Transition.....	60
DO Block Access.....	60
10. DI Function Block.....	61
General.....	61
Modes.....	62
PV Value (PV_D).....	62
Filtering.....	62
Output.....	62
IO_OPTS and STATUS_OPTS.....	63
Alarm Processing.....	64
Block Alarms.....	64
Discrete Alarm.....	64
Channel Parameter Applications.....	64
DI Block Access.....	65
11. AR (Arithmetic) Function Block.....	67
General.....	67
Functions Supported.....	69
Supported Modes.....	70
Alarm Types.....	70
Mode Handling.....	70
Status Handling.....	70
Initialization.....	70
Power Failure Recovery.....	70
AR Block Access.....	71

## Document Changes

Version/Date	Changes
A/05-2014	Original release
B/5-2014	Performed formatting changes.

# 1. Introduction and Safety Information

## Introduction

This manual explains the functioning of the FOUNDATION Fieldbus blocks used in the SVI FF firmware. The basis for these block descriptions are extracted for the FOUNDATION Fieldbus document: FOUNDATION™ Specification Function Block Application Process Part 1 (FF-891), Part 2 (FF-892) and Part 4 (FF-893). These documents were then edited and amended to describe GE's implementation.

It is the customer's responsibility to know how to use their Host DCS with GE function blocks. GE does not provide specific instructions for each DCS and each function block (used individually or in combination).

## Safety Information

This section provides safety information including safety symbols that are used on the SVI FF and the safety symbol definition.

**CAUTION**

*Read this entire section before installation and operation.*



## Safety Symbols

SVI FF instructions contain **WARNINGS**, **CAUTIONS** labels and **Notes**, where necessary, to alert you to safety related or other important information. Total compliance with all **WARNING**, and **CAUTION** notices is required for safe operation.

### WARNING



*Indicates a potentially hazardous situation, which if not avoided could result in serious injury.*

### CAUTION



*Indicates a potentially hazardous situation, which if not avoided could result in property or data damage.*

### NOTE



*Indicates important facts and conditions.*

## SVI FF Product Safety

The SVI FF digital valve positioner is intended for use with industrial compressed air or, natural gas systems only.

### NOTE



*Installations using natural gas are Zone 0 or Div 1 installations.*

Ensure that an adequate pressure relief provision is installed when the application of system supply pressure could cause peripheral equipment to malfunction. Installation must be in accordance with local and national compressed air and instrumentation codes.

### *General installation, maintenance or replacement*

- Products must be installed in compliance with all local and national codes and standards by qualified personnel using safe site work practices. Personal Protective Equipment (PPE) must be used per safe site work practices.
- Ensure proper use of fall protection when working at heights, per safe site work practices. Use appropriate safety equipment and practices to prevent the dropping of tools or equipment during installation.
- Under normal operation, compressed supply gas is vented from the SVI FF to the surrounding area, and may require additional precautions or specialized installations.



## *Intrinsically Safe Installation*

Products certified as explosion proof or flame proof equipment or for use in intrinsically safe installations *MUST BE*:

- Installed, put into service, used and maintained in compliance with national and local regulations and in accordance with the recommendations contained in the relevant standards concerning potentially explosive atmospheres.
- Used only in situations that comply with the certification conditions shown in this document and after verification of their compatibility with the zone of intended use and the permitted maximum ambient temperature.
- Installed, put into service and maintained by qualified and competent professionals who have undergone suitable training for instrumentation used in areas with potentially explosive atmospheres.

### **WARNING**



*Before using these products with fluids/compressed gases other than air or for non-industrial applications, consult the factory. This product is not intended for use in life support systems.*

*Under certain operating conditions, the use of damaged instruments could cause a degradation of the performance of the system, which can lead to personal injury or death.*

*Under certain operating conditions the SVI FF High Flow unit can produce noise levels greater than 85 dBA. Perform proper site monitoring and testing to verify the need for engineering or administrative controls to eliminate or reduce hazardous noise levels.*

*Installation in poorly ventilated confined areas, with any potential of gases other than oxygen being present, can lead to a risk of personnel asphyxiation.*

Use only genuine replacement parts which are provided by the manufacturer, to guarantee that the products comply with the essential safety requirements of the European Directives.

Changes to specifications, structure, and components used may not lead to the revision of this manual unless such changes affect the function and performance of the product.


*This page intentionally left blank.*

# 2. AO Function Block

## General


The AO function block receives the control signal from the transducer block and outputs it to the actuator. The major functions of the AO function block include (Figure 1):

- Scaling
- Setpoint limiters - for both the value and rate of change
- Simulation
- Valve position feedback
- Actions upon abnormality of upstream block
- Signal inversion



**Figure 1** Inputs/Outputs of AO Function Block

The AO function block performs bi-directional signal handling (Figure 2): transfer of the valve control signal to the transducer block (forward path) and feedback of the valve position signal from the transducer block to the upstream block (backward path).



**Figure 2 Function Diagram of AO Function Block**

## Modes

The target mode for the AO function block can be set from five block modes: RCas, Cas, Auto, Man, and O/S. Regardless of the target mode, the AO block automatically enters the IMan or LO mode when a specified condition is met (such as when another function block enters a specific status) depending on the parameter settings.

## Forward Path

The following describes the signal input from the upstream block to the AO block and then passed to the transducer block. The upstream block is typically the PID controller block, and the control signal from the PID block is input as the source of computing the setpoint SP for the AO block.

The path for computing the SP differs depending on the mode: In Cas mode, `CAS_IN` is used for SP. In RCas mode, `RCAS_IN` is used for SP. If the value of `CAS_IN` or `RCAS_IN`, whichever is used, is greater than `SP_HI_LIM` (high limit) or less than `SP_LO_LIM` (low limit), the internal SP is set to the respective limits. Also, if the rate of change in the value of `CAS_IN` or `RCAS_IN`, whichever is used, is greater than `SP_RATE_UP` (rate-of-increase limit) in the increasing direction, or than `SP_RATE_DN` (rate-of-decrease limit) in the decreasing direction, the change in internal SP is limited by the corresponding rate-of-change limit setting.

In RCas, Cas or Auto mode, the SP value is used for the AO block's output `OUT`, whose value is then passed to the transducer block via channel 1.

## Fault State

As for Fieldbus-enabled positioners including the SVI FF, not only a power failure but also other errors (such as a communication error) can cause the fail-safe action. For example, when the status of the CAS\_IN input of the AO block from its upstream block indicates a specific status, such as a communication error, the case is regarded as an abnormality and fault state actions including a mode change are enacted.

When any of the following status exists for the moment of time specified in FSTATE\_TIME, the block goes to the fault state and the mode changes to LO mode:

- Target mode is Cas, and the status of CAS\_IN is *Bad: No Comm*
- Target mode is Cas, and the status of CAS\_IN is *Good: IFS*
- Target mode is RCas, and the status of RCAS\_IN is *Good: IFS*

In LO mode, the block holds the output (OUT) or outputs FSTATE\_VAL, according to the setting of IO\_OPTS. The factory setting is to hold the output.

## Backward Path

The backward path functions as:

1. The valve position signal from the transducer block is written to the AO block parameter READBACK.
2. Is scaled based on XD\_SCALE and PV\_SCALE for conversion to the process variable PV.
3. The value of PV is fed back to the PID block or an upper-level system as the valve position signal via the parameter BKCAL\_OUT and RCAS\_OUT.

If SIMULATE is set to *Enable*, the value of SIMULATE.Simulate\_Value is always set in READBACK.

SIMULATE contains the following data:

<i>Simulate Status</i>	Status to be set in simulation mode.
<i>Simulate Value</i>	Value to be set in simulation mode.
<i>Transducer Status</i>	Status of input from transducer.
<i>Transducer Value</i>	Value of input from transducer.
<i>Enable/Disable</i>	Whether to enable 2 or disable 1 simulation.

## IO\_OPTS and STATUS\_OPTS

These parameters stipulate options about the block's signal processing and mode transitions. The settings of these options are made by setting or resetting the respective bits: on = true, off = false. Table 1 shows the options available in AO block IO\_OPTS.

**Table 1 IO\_OPTS of AO Block**

Bit #	Meaning	Description
1	SP tracks PV if Man	Equalizes SP to PV when target is MAN mode.
3	SP tracks PV if LO	Equalizes SP to PV in LO mode.
4	SP tracks RCas or Cas if LO or Man (SP track retained target)	In LO mode, Equalizes SP to RCAS_IN if target mode is RCas and to CAS_IN if target mode is Cas.
5	Increase to close	Inverts the signal while it goes from SP through OUT.
6	Faultstate Type (Faultstate to value)	Uses a FSTATE_VALUE in LO mode.
7	Faultstate Type (Use Faultstate value on restart)	Uses a value preset for fault state also at a restart.
8	Target to Man	Sets the target mode to Man upon activation of the fault state.
9	PV for BKCAL_OUT	Sets the value of PV in BKCAL_OUT and RCAS_OUT.

Only the Propagate Fault Backward option is available in AO block STATUS\_OPTS.

**Table 2 STATUS\_OPTS of AO Block**

Bit #	Meaning	Description
4	Propagate Fault Backward	<p>Stipulates the handling of the value, data status and related alarm of BKCAL_OUT and RCAS_OUT to be performed.</p> <p>If this option is true, then:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Set the quality and sub-status components of the status of BKCAL_OUT to Bad and sensor failure, respectively.</li> <li><input type="checkbox"/> Do nothing for the BKCAL_OUT value.</li> </ul> <p>If this option is false, then:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Set the quality and sub-status components of the status of BKCAL_OUT to Bad and non specific, respectively.</li> <li><input type="checkbox"/> Generates a block alarm.</li> </ul>


## Mode Shedding on Computer Failure

When the data status of RCAS\_IN falls to Bad while the block is running in RCas (remote cascade) mode, mode shedding occurs in accordance with the setting in SHED\_OPT. Table 3 shows the available selections for the AO block SHED\_OPT setting.

**Table 3 SHED\_OPT of AO Block**

Bit #	Available Setting for SHED_OPT	Actions upon Computer Failure
1	Normal shed, normal return	Sets MODE_BLK.actual to Cas(*1), and leaves MODE_BLK.target unchanged.
2	Normal shed, no return	Sets both MODE_BLK.actual and MODE_BLK.target to Cas(*1).
3	Shed to Auto, normal return	Sets MODE_BLK.actual to Auto(*2), and leaves MODE_BLK.target unchanged.
4	Shed to Auto, no return	Sets both MODE_BLK.actual and MODE_BLK.target to Auto(*2).
5	Shed to Manual, normal return	Sets MODE_BLK.actual to Man, and leaves MODE_BLK.target unchanged.
6	Shed to Manual, no return	Sets both MODE_BLK.actual and MODE_BLK.target to Man.
7	Shed to retained target, normal return	<p>If Cas is set in MODE_BLK.target,</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> sets MODE_BLK.actual to Cas</li> <li>and</li> <li><input type="checkbox"/> leaves MODE_BLK.target unchanged.</li> </ul> <p>If Cas is not set in MODE_BLK.target,</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> sets MODE_BLK.actual to Auto(*2) and</li> <li><input type="checkbox"/> leaves MODE_BLK.target unchanged.</li> </ul>
8	Shed to retained target, No return	<p>If Cas is set in MODE_BLK.target, sets:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> MODE_BLK.actual to Cas, and</li> <li><input type="checkbox"/> MODE_BLK.target to Cas, too.</li> </ul> <p>If Cas is not set in MODE_BLK.target, sets:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> MODE_BLK.actual to Auto(*2),</li> <li>and</li> <li><input type="checkbox"/> MODE_BLK.target to Cas.</li> </ul>

(\*1) The modes to which the AO block can transfer are limited to those set in MODE\_BLK.permitted, and the priority levels of modes (Figure 3). In fact, if Normal shed, normal return is set for SHED\_OPT, the detection of a computer failure causes MODE\_BLK.actual to change to Cas, Auto, or Man, whichever is set in MODE\_BLK.permitted and has the lowest priority level.



**Figure 3 Mode Priority Levels**

(\*2) Only when Auto is set as permitted mode.



*If a control block is connected as a cascade primary block of the AO block, a mode transition of the AO block to Cas occurs in the following sequence due to initialization of the cascade connection: RCas → Auto → Cas.*

## Initialization at Start

To prevent a sudden change in output when the AO block carries out the specified actions for the first time after the power is turned on, it:

1. Equalizes SP to PV if the Faultstate Type option (bit no. 7) in IO\_OPTS is false.
2. Equalizes OUT to READBACK.

If the Faultstate Type option (bit no. 7) in IO\_OPTS is true, it restores FSTATE\_VAL in SP.



## Alarm Processing

When a condition shown in Table 4 is met, the AO block changes the bit statuses of BLOCK\_ERROR accordingly and generates a block alarm.

**Table 4 BLOCK\_ERROR in AO Block**

Bit #	Name of Error Represented	Condition
3	Simulate Active	SIMULATE is active.
4	Local Override	Fault state is on, and Propagate Fault Backward is false.
7	Input Failure / process variable has BAD status	Propagate Fault Backward in STATUS_OPTS is false, and the sub-status component of the status of READBACK is sensor failure or device failure.
15	Out-of-Service	The target mode is O/S.

## BLOCK\_ERR\_DESC\_1 Parameter

See "BLOCK\_ERR\_DESC\_1 Parameter" on page 42.

## Channel Parameter Applications

**Table 5 Channels for Analog Output Blocks**

Channel Value	Usage	Behavior
0	Not Configured	Prevents the Analog Output block from going into Auto Mode.
1	Position	Update the FINAL_VALUE parameter in the Transducer block. Readback is provided from FINAL_POSITION_VALUE. Blocks the switching of the AO block to Auto mode if the TB.SETPOINT_SOURCE is not equal to 1 (Analog Output block). Reports an error for the setting mismatch.

## Minimal Configuration

XD\_SCALE.UNIT = %

CHANNEL = 1 (POSITION CONTROL)

# AO Block Access


**Table 6 AO Block Access**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2	16	READBACK	5		5	
2	TAG_DESC					17	CAS_IN	5		5	
3	STRATEGY				2	18	SP_RATE_DN				4
4	ALERT_KEY				1	19	SP_RATE_UP				4
5	MODE_BLK	4		4		20	SP_HI_LIM		4		
6	BLOCK_ERR	2		2		21	SP_LO_LIM		4		
7	PV	5		5		22	CHANNEL				2
8	SP	5		5		23	FSTATE_TIME				4
9	OUT	5		5		24	FSTATE_VAL				4
10	SIMULATE					25	BKCAL_OUT			5	
11	PV_SCALE		11			26	RCAS_IN			5	
12	XD_SCALE		11			27	SHED_OPT				1
13	GRANT_DENY		2			28	RCAS_OUT			5	
14	INPUT_OPTS				2	29	UPDATE_EVT				
15	STATUS_OPTS					30	BLOCK_ALM				
Sub totals		23	26	23	9	31	BLOCK_ERR_DESC_1				
						Sub totals		23	26	48	7
						Totals		23	26	48	68

# 3. PID Function Block

## General


The PID function block receives an input signal (Figure 4), performs PID control computation, and outputs the control signal, like a single-loop controller.



**Figure 4** Inputs/Outputs of PID Function Block

In practice, it performs PID computation based on the setpoint (SP) set in the actual mode and the process value (PV), and generates a value of its output OUT so as to decrease the deviation. The PID block works with other function blocks such as the AI and AO blocks connected to it. The major functions of the PID block include (Figure 5):

- Filtering
- Setpoint limiters - both for the value and rate of change
- Scaling of process variable (PV), setpoint (SP), and output (OUT)
- PID control computation
- Control action bypass
- Feed-forward
- External-output tracking
- Measured-value tracking
- Output limiters
- Mode shedding upon computer failure
- Alarm generation



**Figure 5 Function Diagram of PID Function Block**

## Modes

The target mode for the PID function block can be set from five block modes: ROut, RCas, Cas, Auto, Man, and O/S. Regardless of the target mode, the PID block automatically enters the IMan or LO mode when a specified condition is met (such as when another function block enters a specific status), depending on the parameter settings.

## Input Processing

The input signal to IN is filtered through a lag filter whose time constant is set in PV\_FTIME, and then set as the process variable (PV).

## Setpoint (SP) Limiters

The path for selecting the SP differs depending on the mode. In Cas mode, CAS\_IN input is used for SP. In RCas mode, RCAS\_IN input is used for SP. If the value of CAS\_IN or RCAS\_IN, whichever is used, is greater than SP\_HI\_LIM (high limit) or less than SP\_LO\_LIM (low limit), the internal SP is set to the respective limits. When the target mode is Auto or Man, and when SP-PV tracking is not specified at the same time, the rate of change in the setpoint is also limited (by the values of SP\_RATE\_UP and SP\_RATE\_DN).

## PID Computation

You can select from one of five PID computational models by setting the ALGORITHM parameter. Figure 6 through Figure 10 visually describe each of the five user-selectable PID computational models.




Figure 6 Ideal Algorithm




Figure 7 Serial Algorithm




Figure 8 Parallel Algorithm




Figure 9 I-PD Algorithm




Figure 10 IP-D Algorithm

Table 7 shows the PID control parameters.

**Table 7 PID Control Parameters**

Parameter	Description	Valid Range
GAIN	Proportional gain	0.05 to 20
RESET	Integral time	4x macrocycle to 10,000 (seconds)
RATE	Derivative time	4x macrocycle to infinity
ALGORITHM	Selects PID algorithm	See "PID Computation" on page 21.
TFPID	Filter time for PID algorithm	4x macrocycle to infinity
TFPD	Filter time for proportional derivative portion	4x macrocycle to infinity

## Direction of Control Action


The direction of the control action is determined by the Direct Acting setting in CONTROL\_OPTS (Table 8).

**Table 8 PID Control Parameters**

Value of Direct Acting	Resulting Action
True	The output increases when the input PV is greater than the setpoint SP.
False	The output decreases when the input PV is greater than the setpoint SP.

## Control Action Bypass

The PID control computation can be bypassed to set the SP value in the control output OUT (Figure 11). Setting BYPASS to ON bypasses the PID control computation.



**Figure 11 Control Action Bypass**

## Feed-forward

Feed-forward adds a compensation input signal FF\_VAL to the output of the PID control computation and is typically used for feed-forward control. In practice, the value of the change in FF\_VAL is scaled to the range of the OUT, multiplied by the value of FF\_GAIN, and then added to the PID control computation result, as illustrated by Figure 12.

When the status of FF\_VAL is Bad, the value of LUV (Last usable value) is used instead of FF\_VAL. If LUV contains no value, the feed-forward action is not carried out.




Figure 12 Feed-forward

## External-output Tracking (LO)

External-output tracking outputs the value of the remote output **TRK\_VAL** set from outside the PID block (Figure 13). External tracking is performed when the block mode is LO.




Figure 13 External-value Tracking

To change the block mode to LO:

1. Set Track Enable in **CONTROL\_OPTS** (see "CONTROL\_OPTS" on page 25) to true.
2. Set **TRK\_IN\_D** to true.

However, to change the block mode from Man to LO, Track in Manual must also be set as true in **CONTROL\_OPTS**.



## Measured-value Tracking

Measured-value tracking, also referred to as SP-PV tracking, is the action of equalizing the setpoint SP to the measured value PV when the block mode (MODE\_BLK.actual) is Man in order to prevent a sudden change in control output from being caused by a mode change to Auto.

While a cascade primary control block is performing automatic control in Auto or Cas mode, when the mode of its secondary control block is changed from Cas to Auto, the cascade connection is opened and the control action of the primary block stops. The SP of the primary controller can also be equalized to its cascade input signal CAS\_IN in this case.

The settings for measured-value tracking are made in the parameter CONTROL\_OPTS (Table 9).

## CONTROL\_OPTS

CONTROL\_OPTS is a parameter that stipulates control options (Table 9).

**Table 9 CONTROL\_OPTS of PID Block**

Bit #	Options in CONTROL_OPTS	Description
0	Bypass Enable	Switch for activating the control action bypass
1	SP-PV Track in Man	Equalizes SP to PV when MODE_BLK.target is set to Man.
2	SP-PV Track in Rout	Equalizes SP to PV when MODE_BLK.target is set to ROut.
3	SP-PV Track in LO or IMan	Equalizes SP to PV when MODE_BLK.actual is set to LO or IMan.
4	SP Track retained Target	Equalizes SP to RCAS_IN or CAS_IN when MODE_BLK.target is either in IMan, LO, Man or ROut and MODE_BLK.actual is set to RCas or Cas.
5	Direct Acting	Set the PID block to be a direct acting controller.
7	Track Enable	While this option is set, if the value of TRK_IN_D becomes 1, the mode transfers to LO.
8	Track in Manual	Set this option when the mode should be transferred to LO even when MODE_BLK.target is set to Man. This option is invalid when Track Enable option is not set.
9	Use PV for BKCAL_OUT	Sets the value of PV in BKCAL_OUT and RCAS_OUT, instead of the value of SP.
12	Obey SP limits if Cas or RCas	Puts the setpoint high/low limits in force in the Cas or RCas mode.
13	No OUT limits in Manual	Disables the high/low limits for OUT in the Man mode.

## Initialization and Manual Fallback (IMan)

Initialization and manual fallback denotes a set of abnormality handling actions in which a PID block changes mode to IMan (initialization manual) and suspends the control action. Initialization and manual fallback takes place only when the following condition is met:

- The quality component of BKCAL\_IN.status (data status of BKCAL\_IN) is Bad.
- OR
- The quality component of BKCAL\_IN.status is Good (c)
- AND
- The sub-status component of BKCAL\_IN.status is FSA, LO, NI, or IR.

## STATUS\_OPTS

Table 10 shows the options in STATUS\_OPTS.

**Table 10 STATUS\_OPTS of PID Block**

Bit #	Options in CONTROL_OPTS	Description
0	IFS if BAD IN	Sets the sub-status component of OUT.status to IFS if IN.status is Bad except when PID control bypass is on.
1	IFS if BAD CAS IN	Sets the sub-status component of OUT.status to IFS if CAS_IN.status is Bad.
2	Use Uncertain as Good	Does not regard IN as being in Bad status when IN.status is Uncertain (to prevent mode transitions from being affected when it is Uncertain).
5	Target to Manual if BAD IN	Automatically changes the value of MODE_BLK.target to Man when IN falls to Bad status.
9	Target to next permitted mode if BAD CAS IN	Automatically changes the value of MODE_BLK.target to Auto (or to Man if Auto is not set in Permitted) when CAS_IN falls to Bad status.

## Auto Fallback

Auto fallback is when a PID block changes mode from Cas to Auto and continues automatic PID control with the user-set setpoint. To enable the auto fallback action to take place:

- The Target to next permitted mode if BAD CAS IN option must be preset to true in STATUS\_OPTS.

AND

- Auto must be preset in MODE\_BLK.permitted.

If the above settings are made, auto fallback takes place automatically when the following condition is met:

- CAS\_IN.status (data status of cascade setpoint) is Bad except when the control action bypass is on.

## Mode Shedding on Computer Failure

Mode shedding occurs in accordance with the SHED\_OPT setting when:

- (1) the data status of RCAS\_IN, which is the setting received from a computer as the setpoint SP, falls to Bad while the PID block is running in the RCas (remote cascade) mode,

or

- (2) the data status of ROUT\_IN, which is the setting received from a computer as the remote output signal, falls to Bad while the PID block is running in the ROut (remote output) mode


**Table 11 STATUS\_OPTS of PID Block**

Available Setting for SHED_OPT	Actions upon Computer Failure
Normal shed, normal return	Sets MODE_BLK.actual to Cas(*1 below the table), and leaves MODE_BLK.target unchanged.
Normal shed, no return	Sets both MODE_BLK.actual and MODE_BLK.target to Cas(*1 below the table).
Shed to Auto, normal return	Sets MODE_BLK.actual to Auto(*2 below the table), and leaves MODE_BLK.target unchanged.
Shed to Auto, no return	Sets both MODE_BLK.actual and MODE_BLK.target to Auto(*2 below the table).
Shed to Manual, normal return	Sets MODE_BLK.actual to Man, and leaves MODE_BLK.target unchanged.
Shed to Manual, no return	Sets both MODE_BLK.actual and MODE_BLK.target to Man.

**Table 11 STATUS\_OPTS of PID Block**

Available Setting for SHED_OPT	Actions upon Computer Failure
Shed to retained target, normal return	If Cas is set in MODE_BLK.target, - sets MODE_BLK.actual to Cas(*1 below the table) and <input type="checkbox"/> leaves MODE_BLK.target unchanged. If Cas is not set in MODE_BLK.target, <input type="checkbox"/> sets MODE_BLK.actual to Auto(*2 below the table) and <input type="checkbox"/> leaves MODE_BLK.target unchanged.
Shed to retained target, no return	If Cas is set in MODE_BLK.target, sets: <input type="checkbox"/> MODE_BLK.actual to Cas, and <input type="checkbox"/> MODE_BLK.target to Cas(*1 below the table), too. If Cas is not set in MODE_BLK.target, sets: <input type="checkbox"/> MODE_BLK.actual to Auto(*2 below the table), and <input type="checkbox"/> MODE_BLK.target to Cas.

(\*1) The modes to which the PID block can transfer are limited to those set in MODE\_BLK.permitted, and the priority levels of modes (Figure 14). In fact, if Normal shed, normal return is set for SHED\_OPT, detection of a computer failure causes MODE\_BLK.actual to change to Cas, Auto, or Man, whichever is set in MODE\_BLK.permitted and has the lowest priority level.



**Figure 14 Priority Levels**

(\*2) Only when Auto is set as permitted mode.

**NOTE**



*If a control block is connected as a cascade primary block of the PID block in question, a mode transition of the PID block to Cas occurs in the following sequence due to initialization of the cascade connection: RCas or ROut → Auto → Cas.*

## Alarms

There are two kinds of alarms generated by a PID block: block and process alarms.

## Block Alarm (BLOCK\_ALM)

The block alarm BLOCK\_ALM is generated on occurrence of the errors in Table 12 (values set in BLOCK\_ERR) and notifies the content of BLOCK\_ERR.

**Table 12 Block Alarm (BLOCK\_ALM)**

Value of BLOCK_ERR	Condition
Input Failure	IN.status of the PID block is either of the following: <input type="checkbox"/> Bad-Device Failure <input type="checkbox"/> Bad-Sensor Failure
Local Override	MODE_BLK.actual of the PID block is LO.
Out of Service	MODE_BLK.target of the PID block is O/S.

## Process Alarms

There are six types of process alarms (Table 13). Only one process alarm can be generated at a time, and the process alarm having the highest priority level from among those occurring at the same time is generated. The priority level is set for each process alarm type.

**Table 13 Process Alarms**

Process Alarm	Cause of Occurrence	Parameter Containing Priority Level Setting
HI_HI_ALM	Occurs when the PV increases above the HI_HI_LIM value.	HI_HI_PRI
HI_ALM	Occurs when the PV increases above HI_LIM value.	HI_PRI
LO_ALM	Occurs when the PV decreases below the LO_LIM value.	LO_PRI
LO_LO_ALM	Occurs when the PV decreases below the LO_LO_LIM value.	LO_LO_LIM
DV_HI_ALM	Occurs when the value of [PV - SP] increases above the DV_HI_LIM value.	DV_HI_PRI
DV_LO_ALM	Occurs when the value of [PV - SP] decreases below the DV_LO_LIM value.	DV_LO_PRI

## BLOCK\_ERR\_DESC\_1 Parameter

See "BLOCK\_ERR\_DESC\_1 Parameter" on page 42.

# PID Block Access

**Table 14 PID Block Access**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2	34	SHED_OPT				1
2	TAG_DESC					35	RCAS_OUT			5	
3	STRATEGY				2	36	ROUT_OUT			5	
4	ALERT_KEY				1	37	TRK_SCALE				11
5	MODE_BLK	4		4		38	TRK_IN_D	2		2	
6	BLOCK_ERR	2		2		39	TRK_VAL	5		5	
7	PV	5		5		40	FF_VAL			5	
8	SP	5		5		41	FF_SCALE				11
9	OUT	5		5		42	FF_GAIN				4
10	PV_SCALE		11		2	43	UPDATE_EVT				
11	OUT_SCALE	5	11	5		44	BLOCK_ALM				
12	GRANT_DENY		2			45	ALARM_SUM	8		8	
13	CONTROL_OPTS				2	46	ACK_OPTION				2
14	STATUS_OPTS				2	47	ALARM_HYS				4
15	IN			5		48	HI_HI_PRI				1
16	PV_FTIME				4	49	HI_HI_LIM				4
17	BYPASS		1			50	HI_PRI				1
18	CAS_IN	5		5		51	HI_LIM				4
19	SP_RATE_DN				4	52	LO_PRI				1
20	SP_RATE_UP				4	53	LO_LIM				4
21	SP_HI_LIM		4			54	LO_LO_PRI				1
22	SP_LO_LIM		4			55	LO_LO_LIM				4
23	GAIN				4	56	DV_HI_PRI				1
24	RESET				4	57	DV_HI_LIM				4

**Table 14 PID Block Access (Continued)**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
25	BAL_TIME				4	58	DV_LO_PRI				1
26	RATE				4	59	DV_LO_LIM				4
27	BKCAL_IN			5		60	HI_HI_ALM				
28	OUT_HI_LIM		4			61	HI_ALM				
29	OUT_LO_LIM		4			62	LO_ALM				
30	BKCAL_HYS				4	63	LO_LO_ALM				
31	BKCAL_OUT			5		64	DV_HI_ALM				
32	RCAS_IN			5		65	DV_LO_ALM				
33	ROUT_IN			5		66	BLOCK_ERR_DESC_1				
Sub totals		28	43	53	41	67	ALGORITHM				
						68	TFPD				
						69	TFPID				
						Sub totals		15	0	30	63
						Totals		43	43	83	104

*This page intentionally left blank.*



# 4. Analog Input

## Overview

The AI block takes the manufacturer's input data, selected by channel number, and makes it available to other function blocks at its output.




Figure 15 Inputs/Outputs of Analog Input (AI) Function Block

## Schematic




Figure 16 Function Diagram of Analog Input Function Block

## Description

Transducer scaling (XD\_SCALE) is applied to the value from the channel to produce the FIELD\_VAL in percent. The XD\_SCALE units code must match the channel units code (if one exists), or the block will remain in O/S mode after being configured. A block alarm for units mismatch will be generated. The OUT\_SCALE is normally the same as the transducer, but if L\_TYPE is set to Indirect or Ind Sqr Root, OUT\_SCALE determines the conversion from FIELD\_VAL to the output. PV and OUT always have identical scaling. OUT\_SCALE provides scaling for PV. The PV is always the value that the block places in OUT if the mode is Auto. If Man is allowed, someone may write a value to the output. The status prevents any attempt at closed loop control using the Man value, by setting the Limit value to Constant.

The LOW\_CUT parameter has a corresponding *Low cutoff* option in the IO\_OPTS bit string. If the option bit is true, any calculated output below the low cutoff value is changed to zero. This is only useful for zero based measurement devices, such as flow.

The PV filter, whose time constant is PV\_FTIME, is applied to the PV, and not the FIELD\_VAL. Equations:

*FIELD\_VAL = 100\*(channel value - EU@0%) / (EU@100% - EU@0%) [XD\_SCALE] Direct: PV = channel value*

*Indirect: PV = (FIELD\_VAL/100) \* (EU@100% - EU@0%) + EU@0% [OUT\_SCALE]*

*Ind Sqr Root: PV = sqrt(FIELD\_VAL/100) \* (EU@100% - EU@0%) + EU@0% [OUT\_SCALE]*

### NOTE



*Sqr Root is not recommended for SVI FF applications. This is reserved for future use.*

## Channel Parameter Applications

**Table 15 Channels for Analog Input Blocks**

Channel Value	Usage	Behavior	XD_SCALE. UNIT
0	Not Configured	Prevents the Analog Input block from going into Auto Mode	
7	Supply Pressure	Provides the supply pressure value to the FF control	%
8	Actuator Pressure 1	Provides the Actuator 1 pressure value to the FF control	PSI
9	Actuator Pressure 2	Provides the Actuator 2 pressure value to the FF control	PSI
10	IP Current	Provides the IP current value to the FF control	mA

**Table 15 Channels for Analog Input Blocks (Continued)**

<b>Channel Value</b>	<b>Usage</b>	<b>Behavior</b>	<b>XD_SCALE. UNIT</b>
11	Pilot Pressure	Provides the pilot pressure value to the FF control	PSI
12	Temperature	Provides the board temperature to the FF control	°C
13	Final Value	Provides the Transducer block setpoint to the FF control	%
14	Final Position Value	Provides the Transducer block actual position to the FF control	%
15	Working SP	Provides the Transducer block working setpoint (after characterization) to the FF control	%
16	Working Position	Provides the Transducer block working position (before de-characterization) to the FF control	%

## Supported Modes

O/S, Man, and Auto.

## Alarm Types

Standard block alarm plus standard HI\_HI, HI, LO, and LO\_LO alarms applied to OUT.

## Mode Handling

Standard transition in and out of O/S.

Standard transition from Man to Auto and back.

## Status Handling

The status values described in Output Parameter Formal Model of Part 1 of the FF891 specification apply, with the exception of the control sub-status values. The Uncertain - EU Range Violation status is always set if the OUT value exceeds the OUT\_SCALE range, and no worse condition exists. The following options from STATUS\_OPTS apply, where Limited refers to the sensor limits:

*Propagate Fault Forward*

*Uncertain if Limited*

*BAD if Limited*

*Uncertain if Man mode*

## Initialization

The PV filter must be initialized, but other than that, no special initialization is required. This is a pure calculation algorithm.

## BLOCK\_ERR\_DESC\_1 Parameter

See "BLOCK\_ERR\_DESC\_1 Parameter" on page 42.

## Minimum Configuration

XD\_SCALE.UNITS

OUT\_SCALE.UNITS

CHANNEL

L-TYPE

# Analog Input Block Access

**Table 16 Analog Input Block Access**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2	19	FIELD_VAL	5		5	
2	TAG_DESC					20	UPDATE_EVT				
3	STRATEGY				2	21	BLOCK_ALM				
4	ALERT_KEY				1	22	ALARM_SUM	8		8	
5	MODE_BLK	4		4		23	ACK_OPTION				2
6	BLOCK_ERR	2		2		24	ALARM_HYS				4
7	PV	5		5		25	HI_HI_PRI				1
8	OUT	5		5		26	HI_HI_LIM				4
9	SIMULATE					27	HI_PRI				1
10	XD_SCALE		11			28	HI_LIM				4
11	OUT_SCALE		11			29	LO_PRI				1
12	GRANT_DENY		2			30	LO_LIM				4
13	IO_OPTS				2	31	LO_LO_PRI				1
14	STATUS_OPTS				2	32	LO_LO_LIM				4
15	CHANNEL				2	33	HI_HI_ALM				
16	L_TYPE				1	34	HI_ALM				
17	LOW_CUT				4	35	LO_ALM				
18	PV_FTIME				4	36	LO_LO_ALM				
Sub totals		18	26	18	20	37	BLOCK_ERR_DESC_1				
						Sub totals		13	0	13	26
						Totals		31	26	31	46

*This page intentionally left blank.*

# 5. Control Selector

## Overview

The Control Selector block is intended to select one of two or three control signals in a manner determined by SEL\_TYPE, when the block is in Auto mode. The Control Selector should be distinguished from the Input Selector block, which is used for selecting a measurement from input or calculation blocks.




Figure 17 Inputs Outputs of Control Selector Function Block

# Schematic




Figure 18 Function Diagram of Control Selector Function Block

# Description

All inputs to the selector block are assumed to have the same scaling as OUT, since any one of them may be selected to be OUT. Three separate BKCAL\_SEL\_N outputs are available, one for each SEL\_N input. The status indicates those inputs that are not selected. Control blocks that are not selected are limited in one direction only, determined by the type of selector. The value of each BKCAL\_SEL\_N output is the same as OUT. The limits of back calculation outputs corresponding to deselected inputs are high for a low selector and low for a high selector, or one of each for a mid selector.




Figure 19 Control Selector Block Example



## Supported Modes

O/S, IMan, Man, and Auto.

## Alarm Types

Standard block alarm.

## Mode Handling

Standard transition in and out of O/S.

## Status Handling

If an input is Uncertain, it is treated as Bad unless the status option Use Uncertain as Good is set.

When any inputs is Bad, the actual mode goes to Man, as it does for a bad primary input to a PID. This condition sets IFS in the output status if the option IFS if BAD IN is set in STATUS\_OPTS.

If the status of BKCAL\_IN is NI (Not Invited) or IR, it is passed back on all three BKCAL outputs. This causes all initializable inputs to initialize to the BKCAL\_IN value. Otherwise, if the status of BKCAL\_IN is not normal, it is passed back on BKCAL\_SEL\_Y, where Y is the number of the selected input. The BKCAL\_SEL\_X outputs for deselected inputs just have the Not Selected status with the appropriate high or low limit set.

When the block is in Man mode, no input is selected. All three BKCAL outputs have a Not Invited status and Constant limits, with a value equal to OUT.

## Initialization

Standard.

## BLOCK\_ERR\_DESC\_1 Parameter

Table 17 lists the common block errors that can occur.

**Table 17 Common Block Errors**

Hex	Description
0x40000000U	CHANNEL parameter is not set
0x20000000U	Incorrect CHANNEL parameter value
0x10000000U	
0x08000000U	L_TYPE parameter is set for Direct, but input and output scale does not match
0x02000000U	XD_SCALE upper and lower range not set correctly
0x01000000U	OUT_SCALE upper and lower range not set correctly
0x00800000U	PV_SCALE upper and lower range not set correctly
0x00400000U	TRK_SCALE upper and lower range not set correctly
0x00200000U	FF_SCALE upper and lower range not set correctly
0x00100000U	BYPASS parameter is not set
0x00080000U	SHED_OPT parameter is not set
0x00040000U	SP_HI_LIM or SP_LO_LIM parameters are not set correctly
0x00020000U	OUT_HI_LIM or OUT_LO_LIM parameters are not set correctly
0x00010000U	ARITH_TYPE Parameter is not set
0x00008000U	SEL_TYPE Parameter is not set
0x00002000U	RANGE_HI or RANGE_LO parameters are not set correctly
0x00001000U	COMP_HI_LIM or COMP_LO_LIM parameters are not set correctly
0x00000040U	IN_ARR parameter values are not consistent
0x00000020U	LOCKVAL Parameter is not set
0x00000001U	Block is not scheduled

# Control Selector Block Access

**Table 18 Control Selector Block Access**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2	12	SEL_2	5		5	
2	TAG_DESC					13	SEL_3	5		5	
3	STRATEGY				2	14	SEL_TYPE				1
4	ALERT_KEY				1	15	BKCAL_IN			5	
5	MODE_BLK	4		4		16	OUT_HI_LIM		4		
6	BLOCK_ERR	2		2		17	OUT_LO_LIM		4		
7	OUT	5		5		18	BKCAL_SEL_1			5	
8	OUT_SCALE		11			19	BKCAL_SEL_2			5	
9	GRANT_DENY		2			20	BKCAL_SEL_3			5	
10	STATUS_OPTS				2	21	UPDATE_EVT				
11	SEL_1	5		5		22	BLOCK_ALM				
Sub totals		18	26	18	20	23	BLOCK_ERR				
						Sub totals		10	8	30	1
						Totals		28	23	48	8

*This page intentionally left blank.*

# 6. OS Function Block

## General

The output splitter block provides the capability to drive two control outputs from a single input (Figure 20). Each output is a linear function of some portion of the input. Back calculation support is provided using the same linear function in reverse. Cascade initialization is supported by a decision table for combinations of input and output conditions.

This block would normally be used in split ranging or sequencing of multiple valve applications.

A typical split range application has both valves closed when the splitter setpoint is about 50%. One of the valves opens fully as the input drops to 0%. The other valve opens as the input rises above 50%.

A typical sequencing application has both valves closed at 0% input. One valve opens fully as the SP rises to about 50%, and the other stays shut. The second valve opens as the input rises above 50%, and the first valve may remain open or shut off quickly.





Figure 20 Inputs/Outputs of OS Function Block

The OS block receives a control signal and converts it into two signals in accordance with the predefined relationships. The major functions of the OS block include (Figure 21):

- Conversion of the setpoint (SP) value into two output values (OUT\_1 and OUT\_2) in accordance with the user-specified characteristics (set in IN\_ARRAY and OUT\_ARRAY)
- Generation of the output value to be fed back to the upstream block (BKCAL\_OUT).




**Figure 21 Function Diagram of OS Function Block**

## Modes

Follows normal FF modes.

## Output Processing

The values of OUT\_1 and OUT\_2 with respect to the value of SP, which is the value of the input from the upstream block (CAS\_IN) in the Cas mode or the local setpoint value in the Auto mode, are determined as shown in Figure 22.



**Figure 22 Examples of Valve Operation Characteristics**

These characteristics are determined by the array element values in parameters:

- IN\_ARRAY and OUT\_ARRAY
- IN\_ARRAY: [X11, X12, X21, X22]
- OUT\_ARRAY: [Y11, Y12, Y21, Y22]

Coordinates P1 (X11, Y11) and P2 (X12, Y12) define the start and stop points of the characteristics for OUT\_1, and P3 (X21, Y21) and P4 (X22, Y22) define those for OUT\_2. These two operation characteristics may overlap each other, or start from the same point and have different slopes; however, all the following conditions must be met at all times. Settings of IN\_ARRAY that do not meet one or more of these conditions cause a BLOCK\_ERR, disabling the block from exiting the O/S mode.

- X21 . X11
- X12 > X11
- X22 > X21


In areas outside the endpoints (i.e., start and stop points) of each operation characteristic, the output is retained at the Y value at the nearer end point. For OUT\_1, however, depending on the setting of LOCKVAL, it is possible to:

Set the value of OUT\_1 to Y11 in the areas outside the endpoints if SP is greater than X12 and if LOCKVAL is false.

When this action is enabled, the value set in HYSTVAL serves as hysteresis, which affects the output as follows (Figure 23):

When SP has increased beyond X12, OUT\_1 is set to Y11.

Then, after SP has decreased below X12 minus HYSTVAL, OUT\_1 returns to follow the set characteristic.



**Figure 23 LOCKVAL and HYSTVAL**

When both downstream blocks of the OS block are ready for cascade connection, the OS block connects the block on the side of OUT\_1 first. For bumpless mode change on the side of OUT\_2, the balancing time for connection can be set in BAL\_TIME. When either downstream block alone is ready for cascade connection, the OS block connects it and enters the Cas mode. When neither downstream block is ready for cascade connection, the OS block mode is set to IMan.

## Backward Path (BKCAL\_OUT)

The value of SP or a value calculated from the value of either BKCAL\_IN\_1 or BKCAL\_IN\_2, depending on the handshake status with the downstream blocks, is output through BKCAL\_OUT. In normal operating conditions (i.e., BLK\_MODE.actual is Cas or Auto), BKCAL\_OUT is set to the value of SP.

## BLOCK\_ERR\_DESC\_1 Parameter

See "BLOCK\_ERR\_DESC\_1 Parameter" on page 42.

## OS Block Access

**Table 19 OS Block Access**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2	14	CAS_IN	5		5	2
2	TAG_DESC					15	BKCAL_OUT			5	
3	STRATEGY				2	16	IN_ARRAY				16
4	ALERT_KEY				1	17	OUT_ARRAY				16
5	MODE_BLK	4		4		18	LOCKVAL				1
6	BLOCK_ERR	2		2		19	BKCAL_IN_1			5	
7	SP	5		5		20	BKCAL_IN_2			5	
8	OUT_1	5		5		21	BAL_TIME				4
9	OUT_2	5		5		22	HYSTVAL				4
10	OUT_1_RANGE		11		2	23	UPDATE_EVT				
11	OUT_2_RANGE	5	11	5		24	BLOCK_ALM				
12	GRANT_DENY		2			25	BLOCK_ERROR_DESC				
13	STATUS_OPTS				2						
Sub totals		23	26	27	7	Sub totals		23	26	23	7
						Totals		28	26	43	48



# 7. Multiple Analog Input Function Block (MAI)

## Overview

The MAI block makes available for the FF network eight analog variables of the I/O subsystem through its eight output parameters: OUT\_1 through OUT\_8, whose values must be expressed in engineering units.

Status indication in the OUT\_x output parameters depends on the I/O subsystem and the transducer block. There is individual detection of sensor failure that can be indicated in the status of related OUT\_x parameter.

## Schematic




Figure 24 Function Diagram of Multiple Analog Input Function Block

## Usage

To integrate the positioner related parameters in the control system, you must set *CH\_MAI\_CHANNELS* to 20.

## Supported Modes

O/S, Man and Auto modes are supported.

## Alarm Types

Standard block alarm are supported.

## Mode Handling

Standard transition in and out of O/S.

## Status Handling

The status values described in the Parameter Formal Model of Part 1 apply, with the exception of the control sub-status values.

## Initialization

The initialization is specific to the block algorithm.

## BLOCK\_ERR\_DESC\_1 Parameter

See “BLOCK\_ERR\_DESC\_1 Parameter” on page 42.

## Multiple Analog Input Function Block Access

Table 20 Multiple Analog Input Block Access

Index	Parameter Mnemonic (Parameter Name)	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2
2	TAG_DESC				
3	STRATEGY				2
4	ALERT_KEY				1
5	MODE_BLK	4		4	
6	BLOCK_ERR	2		2	
7	CHANNEL				2
8	OUT_1 (Supply Pressure)	5		5	
9	OUT_2 (Actuator A Pressure)	5		5	
10	OUT_3 (Actuator B Pressure)	5		5	
11	OUT_4 (Pilot Pressure)	5		5	
12	OUT_5 (IP Drive Current)	5		5	
13	OUT_6 (Temperature)	5		5	
14	OUT_7 (Working Setpoint)	5		5	
15	OUT_8 (Working Position)	5		5	
16	UPDATE_EVT				
17	BLOCK_ALM				
18	BLOCK_ERR_DESC_1				
Totals		48	2	48	7

*This page intentionally left blank.*

# 8. Input Selector (IS) Function Block

## General

The signal selector block provides selection of up to four inputs and generates an output based on the configured action (Figure 25). This block normally receives its inputs from AI blocks. The block performs maximum, minimum, middle, average and *first good* signal selection.




Figure 25 Inputs/Outputs of Input Selector (IS) Function Block

With a combination of parameter configuration options the block can function as a rotary position switch, or a validated priority selection based on the use of the first good parameter and the disable\_n parameter (Figure 25). As a switch, the block can receive switching information from either the connected inputs or from an operator input. The block also supports the concept of a middle selection. Although the normal configuration for this feature would be with three signals, the block should generate an average of the middle two if four signals are configured or the average of two if three are configured and a bad status is passed to one of the inputs. Logic is provided for handling uncertain and bad signals in conjunction with configured actions. The intended application of this block is to provide control signal selection in the forward path only, therefore, no back calculation support is provided. SELECTED is a second output that indicates which input has been selected by the algorithm.

## Function Supported

This block is intended to be used in a forward path only and is not intended to receive signals from the output of a controller. There is no back calculation support or propagation of control status values. Because the block is usually connected to AI blocks, there is no need of back calculation. The processing of the block is as follows:

### *Input Processing*

If DISABLE\_n is true then don't process (ignore) the respective input IN\_n.

Process the Use Uncertain as Good status options. Discard (ignore) inputs whose status is bad.

If there are no inputs left, or fewer than MIN\_GOOD inputs, then set the value of SELECTED to zero. Do not do selection processing.

### *Selection Processing*

If OP\_SELECT is non-zero, the OP\_SELECT value shall determine the selected input, regardless of the SELECT\_TYPE selection. Set SELECTED to the number of the input used.

If SELECT\_TYPE is First Good, transfer the value of the first remaining input to the output of the block. Set SELECTED to the number of the input used.

If SELECT\_TYPE is Minimum, sort the remaining inputs by value. Transfer the lowest value to the output of the block. Set SELECTED to the number of the input with the lowest value.


If SELECT\_TYPE is Maximum, sort the remaining inputs by value. Transfer the highest value to the output of the block. Set SELECTED to the number of the input with the highest value.

If SELECT\_TYPE is Middle, sort the remaining inputs by value. If there are 3 or 4 values, discard the highest and lowest value. If two values are left, compute their average. Transfer the value to the output of the block. Set SELECTED to zero if an average was used, else set SELECTED to the number of the input with the middle value.

If SELECT\_TYPE is Average compute the average of the remaining inputs and transfer the value to the output of the block. Set

SELECTED to the number of inputs used in the average.

Figure 26 shows an example use of Input Selector block configured to select the maximum value out of three input blocks.



**Figure 26 Input Selector Block Input Selection Example**

## Supported Modes

O/S, Man, and Auto.

## Alarm Types

Standard block alarm.

## Mode Handling

Standard.

## Status Handling

If there are no inputs used, or fewer than MIN\_GOOD inputs, then the status of OUT shall be set to Bad Non-specific.

The SELECTED output shall have Good(NC) status, unless the block is out of service.

Status options for Use Uncertain as Good and Uncertain if Manual shall be supported.

## Initialization

Standard.

## Power Failure Recovery

Standard.

## BLOCK\_ERR\_DESC\_1 Parameter

See "BLOCK\_ERR\_DESC\_1 Parameter" on page 42.

# Minimum Configuration

SELECT\_TYPE

## IS Block Access

**Table 21 IS Block Access**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2	13	IN_3	5		5	
2	TAG_DESC					14	IN_4	5		5	
3	STRATEGY				2	15	DISABLE_1	2		2	
4	ALERT_KEY				1	16	DISABLE_2	2		2	
5	MODE_BLK	4		4		17	DISABLE_3	2		2	
6	BLOCK_ERR	2		2		18	DISABLE_4	2		2	
7	OUT	5		5		19	SELECT_TYPE				1
8	OUT_RANGE		11			20	MIN_GOOD				1
9	GRANT_DENY		2			21	SELECTED	2		2	
10	STATUS_OPTS				2	22	OP_SELECT	2		2	
11	IN_1	5		5		23	UPDATE_EVT				
12	IN_2	5		5		24	BLOCK_ALM				
Sub totals		23	15	23	7	25	BLOCK_ERR_DESC_1				
						Sub totals		23	15	23	7
						Totals		45	15	45	9



# 9. Discrete Output

## Overview

The DO block converts the value in SP\_D to control the hardware identified by CHANNEL parameters selection.




Figure 27 Inputs Outputs of Discrete Output (AI) Function Block

## Schematic




Figure 28 Function Diagram of Discrete Output Function Block

## Description

The SP\_D supports the full cascade sub-function. Cas mode must be used to transfer the output of another block to the SP\_D of the DO. There are additional I/O options which cause the SP\_D value to track the PV\_D value when the block is in an actual mode of LO or when the target mode for the block is Man.

If the hardware readback value is selected, it is used for READBACK\_D, which, after accounting for the Invert I/O option, acts as the PV\_D for this block. If not supported, READBACK\_D is generated from OUT\_D. The OUT\_D and READBACK\_D parameters both use XD\_STATE. The PV\_D and SP\_D use PV\_STATE.

The Invert I/O option can be used to do a Boolean NOT function between the SP\_D and the hardware. The selected channel influences behavior as in Table 22.

### Channel Parameter Applications

**Table 22 Channels for Discrete Output Blocks**

Channel Value	Domain	Usage	Behavior	Invert Behavior
0	NA	Not Configured	Prevents the Discrete Output block from going into Auto Mode.	NA
2	Position	Open/Close	Updates the FINAL_VALUE_D parameter in the Transducer block. Readback is provided from FINAL_POSITION_VALUE_D. Blocks the switching of the DO block to Auto mode if the TB.SETPOINT_SOURCE is not equal to 2 (DO block in Open/Close mode). Reports an error for the setting mismatch.	OUT_D = 1 if SP_D = 0. OUT_D = 0 if SP_D not equal to 0.
3	Position	Discrete Position (Range: 0 to 100%)	Updates the FINAL_VALUE_DINT parameter in the Transducer block. Readback is provided from FINAL_POSITION_VALUE_DINT. Blocks the switching of the DO block to Auto mode if the TB.SETPOINT_SOURCE is not equal to 3 (Discrete Output block in Discrete Mode). Reports an error for the setting mismatch.	If $SP_D \leq 100\%$ OUT_D = $100\% - SP_D$ . If $SP_D > 100\%$ OUT_D = 0.

**Table 22 Channels for Discrete Output Blocks (Continued)**

Channel Value	Domain	Usage	Behavior	Invert Behavior
4	Discrete	Discrete Switch 1	The DO.OUT value updates the TB.DISCRETE_OUTPUT_1 parameter, which controls the DO1 switch controlled by the APP processor.	
5	Discrete	Discrete Switch 2	The DO.OUT value updates the TB.DISCRETE_OUTPUT_2 parameter, which controls the DO2 switch controlled by the APP processor.	OUT_D = 1 if SP_D = 0. OUT_D = 0 if SP_D not equal to 0.

## Supported Modes

O/S, LO, Iman, Man, Auto, Cas, and RCas. The Man mode can be used to force the output, in a PLC sense. It may be that Man mode is not permitted, but it must be supported so that Man mode may be entered when leaving O/S. The IMan mode is used to indicated that there is no path to the final element.

## Alarm Types

Standard block alarm.

## Mode Handling

Standard transition in and out of O/S.

## Status Handling

The status values described in Output Parameter Formal Model of Part 1 of the FF891 specification apply, with the exception of the control sub-status values. The following options from STATUS\_OPTS apply:

*Propagate Fault Backward*

## Initialization

Standard.

## Fault State Recovery

Standard.

## Bad to Good Output Transition

Use the readback value, if available, or restore the NV value of OUT\_D.

## BLOCK\_ERR\_DESC\_1 Parameter

See "BLOCK\_ERR\_DESC\_1 Parameter" on page 42.

## DO Block Access


**Table 23 DO Block Access**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2	14	IO_OPTS				2
2	TAG_DESC					15	STATUS_OPTS				2
3	STRATEGY				2	16	READBACK_D	2		2	
4	ALERT_KEY				1	17	CAS_IN_D	2		2	
5	MODE_BLK	4		4		18	CHANNEL				2
6	BLOCK_ERR	2		2		19	FSTATE_TIME				4
7	PV_D	2		2		20	FSTATE_VAL_D				1
8	SP_D	2		2		21	BKCAL_OUT_D			2	
9	OUT_D	2		2		22	RCAS_IN_D			2	
10	SIMULATE_D					23	SHED_OPT				1
11	PV_STATE		2			24	RCAS_OUT_D			2	
12	XD_STATE		2			25	UPDATE_EVT				
13	GRANT_DENY		2		2	26	BLOCK_ALM				
Sub totals		14	8	14	5	27	BLOCK_ERR_DESC_1				
						Sub totals		4	0	10	12
						Totals		18	8	24	17

# 10. DI Function Block

## General


An SVI FF contains two DI function blocks, which individually transfer the valve-position high and low limit switch signals generated by the transducer block (Figure 29).



**Figure 29** Inputs/Outputs of DI Function Block

The major functions of a DI function block include (Figure 30):

- Signal inversion (I/O processing option)
- Simulation
- Filtering (time delay)
- Alarm generation



**Figure 30** Function Diagram of DI Function Block

## Modes

The target mode for a DI function block can be set from three block modes: O/S, Auto, and Man.

## PV Value (PV\_D)

A limit switch signal is transferred from the transducer block via a channel. Normally, the Transducer Value and Transducer Status values in SIMULATE\_D are copied to FIELD\_VAL\_D, indicating the on/off status of the corresponding limit switch. If SIMULATE\_D is set to *Enable*, the Simulate Value and Simulate Status values in SIMULATE\_D are copied to FIELD\_VAL\_D.

SIMULATE\_D contains the following data:

<i>Simulate Status</i>	Status to be set in simulation mode
<i>Simulate Value</i>	Value to be set in simulation mode
<i>Transducer Status</i>	Status of input from transducer
<i>Transducer Value</i>	Value of input from transducer
<i>Enable/Disable</i>	Whether to enable 2 or disable 1 simulation

The value of FIELD\_VAL\_D is copied to the process value PV\_D. At this time, if the Invert option (bit 0) is specified as true, the on/off status is inverted (Table 24).

**Table 24** FIELD\_VAL\_D

Value of FIELD_VAL_D	Value of PV_D	
	Invert = False	Invert = True
0	0 (off)	1
≥1	1 (on)	0

## Filtering

Transfer of a change in the value of FIELD\_VAL\_D to the value of PV\_D can be delayed for a desired time period set in the parameter PV\_FTIME (in seconds).

## Output

The value of the output OUT\_D is generated based on the value of PV\_D.

## IO\_OPTS and STATUS\_OPTS

These parameters stipulate options about block's signal processing and mode transitions.

The settings of these options are made by setting or resetting the respective bits: on = true, off = false. Table 25 shows the options available in the DI block IO\_OPTS.

**Table 25 IO\_OPTS of DI Block**

Bit #	Meaning	Description
0	Invert	Inverts the on/off status.

Table 26 shows the options available in the AO block STATUS\_OPTS.

**Table 26 IO\_OPTS of DI Block**

Bit #	Meaning	Description
3	Propagate Fault Forward	<p>Stipulates the handling of the value and data status of OUT_D when the quality component of the data status of SIMULATE_D falls to Bad and the substatus component falls to device failure or sensor failure.</p> <p>If this option is true, then it:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Does not generate a block alarm.</li> <li><input type="checkbox"/> Sets the status and value of SIMULATE_D in OUT_D.</li> </ul> <p>If this option is false, then it:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Generates the <i>input failure</i> block alarm.</li> <li><input type="checkbox"/> Set the quality and sub-status components of the status of OUT_D to Bad and non specific, respectively.</li> </ul>
8	Uncertain if Man mode	Sets the status of OUT_D to uncertain when in Man mode.

# Alarm Processing

## Block Alarms

When a condition shown in Table 27 is met in a DI block, the block changes the bit statuses of BLOCK\_ERROR accordingly and generates a block alarm.

**Table 27 BLOCK\_ERROR in DI Block**

Bit #	Meaning	Description
3	Simulate Active	SIMULATE_D is active.
7	Input Failure / process variable has BAD status	Propagate Fault Backward in STATUS_OPTS is false, and the sub-status component of the status of READBACK is sensor failure or device failure.
15	Out of Service	The target mode is O/S.

## Discrete Alarm

The parameter DISC\_ALM is a discrete alarm of the parameter OUT\_D.

When the value of OUT\_D agrees with the value of DISC\_LIM, the alarm state of DISC\_ALM is set to active and an alert is generated.

## BLOCK\_ERR\_DESC\_1 Parameter

See "BLOCK\_ERR\_DESC\_1 Parameter" on page 42.

## Channel Parameter Applications

**Table 28 Channels for Discrete Input Blocks**

Channel Value	Usage	Behavior
0	Not Configured	Prevents the Discrete Input block from going into Auto Mode.
17	Discrete Input	Provides the state of the discrete input to the FF control.
18	State of Sw1	Sends the state of the discrete Switch 1 from APP processor to the FF control.
19	State of Sw2	Sends the state of the discrete Switch 2 from APP processor to the FF control.



# DI Block Access

**Table 29 DI Block Access**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2	13	IO_OPTS				2
2	TAG_DESC					14	STATUS_OPTS				2
3	STRATEGY				2	15	CHANNEL				2
4	ALERT_KEY				1	16	PV_FTIME				4
5	MODE_BLK	4		4		17	FIELD_VAL_D	2		2	
6	BLOCK_ERR	2		2		18	UPDATE_EVT				
7	PV_D	2		2		19	BLOCK_ALM				
8	OUT_D	2		2		20	ALARM_SUM	8		8	
9	SIMULATE_D					21	ACK_OPTION				2
10	XD_STATE		2			22	DISC_PRI				1
11	OUT_STATE		2			23	DISC_LIM				1
12	GRANT_DENY		2			24	DISC_ALM				
Sub totals		12	8	12	5	25	BLOCK_ERR_DESC_1				
						Sub totals		10	0	10	14
						Totals		22	8	22	19


*This page intentionally left blank.*

# 11. AR (Arithmetic) Function Block

## General

The AR (Arithmetic) block (Figure 31) uses inputs as arguments on a pre-defined set of math functions to calculate an output.

The AR block is intended for use in calculating measurements from combinations of signals from sensors. It is not intended to be used in a control path, so it does not support control status propagation or back calculation. It has no process alarms.




**Figure 31** Inputs/Outputs of AR Function Block

The AR block has five inputs. The first two are dedicated to a range extension function that results in a PV, with status reflecting the input in use.

The remaining three inputs are combined with the PV in a selection of four term math functions that have been found useful in a variety of measurements. The inputs used to form the PV must come from devices with the desired engineering units, so that the PV enters the equation with the right units. Each of the additional inputs has a bias and gain constant. The bias can be used to correct for absolute temperature or pressure. The gain can be used to normalize terms within a square root function. The output also has gain and bias constants for any further adjustment required.

The major functions of the block are shown in Figure 32.



**Figure 32 Function Diagram of AR Function Block**

The range extension function has a graduated transfer, controlled by two constants referenced to IN. An internal value,  $g$ , is zero for IN less than RANGE\_LO. It is one when IN is greater than RANGE\_HI. It is interpolated from zero to one over the range of RANGE\_LO to RANGE\_HI. The equation for PV follows:

$$PV = g * IN + (1-g) * IN\_LO$$

If the status of IN\_LO is unusable and IN is usable and greater than RANGE\_LO, then set  $g$  to one. If the status of IN is unusable, and IN\_LO is usable and less than RANGE\_HI, then set  $g$  to zero. In each case, the PV should have a status of Good until the condition no longer applies. Otherwise, the status of IN\_LO is used for the PV if  $g$  is less than 0.5, while IN is used for  $g$  greater than or equal to 0.5.

Six constants are used for the three auxiliary inputs. Each has a BIAS\_IN\_i and a GAIN\_IN\_i. The output has a BIAS and a GAIN static constant. For the inputs, the bias is added and the gain is applied to the sum. The result is an internal value called  $t_i$  in the function equations. The equation for each auxiliary input is the following:

$$t_i = (IN_i + BIAS\_IN_i) * GAIN\_IN_i$$

The flow compensation functions have limits on the amount of compensation applied to the PV, to assure graceful degradation if an auxiliary input is unstable. The internal limited value is  $f$ .

## Functions Supported

The following function types are supported:

### *Flow compensation, linear*

Used for density compensation of volume flow.

$$\text{func} = f * PV$$

### *Flow compensation, square root*

Usually, IN\_1 is pressure, IN\_2 temperature, and IN\_3 is the compressibility factor Z.

$$\text{func} = f * PV$$

$$f = \sqrt{t\_1 / t\_2 / t\_3} \text{ [limited]}$$

### *Flow compensation, approximate*

Both IN\_2 and IN\_3 would be connected to the same temperature.

$$\text{func} = f * PV$$

$$f = \sqrt{t\_1 * t\_2 * t\_3 * t\_3} \text{ [limited]}$$

### *BTU flow*

Where IN\_1 is inlet temperature, and IN\_2 the outlet temperature

$$\text{func} = f * PV$$

$$f = (t\_1 - t\_2) \text{ [limited]}$$

### *Traditional Multiply Divide*

$$\text{func} = f * PV$$

$$f = (t\_1 / t\_2) + t\_3 \text{ [limited]}$$

### *Average*

$$\text{func} = (PV + t\_1 + t\_2 + t\_3) / f$$

f = number of inputs used in computation (unusable inputs are not used).

### *Traditional Summer*

$$\text{func} = PV + t\_1 + t\_2 + t\_3$$

### *Fourth order polynomial*

All inputs except IN\_LO (not used) are linked together.

$$\text{func} = PV + t\_1 ** 2 + t\_2 ** 3 + t\_3 ** 4$$

### *Simple HTG compensated level*

Where PV is the tank base pressure, IN\_1 is the top pressure, IN\_2 is the density correction pressure, and GAIN is the height of the density tap.

$$\text{func} = (\text{PV} - t_1) / (\text{PV} - t_2)$$

After the value of func is calculated, it is multiplied by GAIN, and then BIAS is added to the result. Finally, high and low output limits are applied, and the result is the term PRE\_OUT. If the mode is Auto, PRE\_OUT becomes OUT.

## **Supported Modes**

O/S, Man, and Auto.

## **Alarm Types**

Standard block alarm.

## **Mode Handling**

The algorithm never changes the mode, even when inputs go bad.

If the mode is changed to Man, an internal value is set to the difference between OUT and the output of the selected function. When the mode is changed to Auto, the difference value exponentially decays to zero with a time constant of BAL\_TIME.

The output of the calculation function appears in PRE\_OUT.

## **Status Handling**

The INPUT\_OPTS bit string controls use of auxiliary inputs with less than good status. The status of unused inputs are ignored.

The status of the output is that of the worst of the inputs used in the calculation after applying INPUT\_OPTS.

## **Initialization**

Standard.

## **Power Failure Recovery**

Standard.

## **BLOCK\_ERR\_DESC\_1 Parameter**

See "BLOCK\_ERR\_DESC\_1 Parameter" on page 42.

# AR Block Access

**Table 30 AR Block Access**

Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4	Index	Parameter Mnemonic	VIEW _1	VIEW _2	VIEW _3	VIEW _4
1	ST_REV	2	2	2	2	19	RANGE_HI				4
2	TAG_DESC					20	RANGE_LO				4
3	STRATEGY				2	21	BIAS_IN_1				4
4	ALERT_KEY				1	22	GAIN_IN_1				4
5	MODE_BLK	4		4		23	BIAS_IN_2				4
6	BLOCK_ERR	2		2		24	GAIN_IN_2				4
7	PV	5		5		25	BIAS_IN_3				4
8	OUT	5		5		26	GAIN_IN_3				4
9	PRE_OUT	5		5		27	COMP_HI_LIM				4
10	PV_SCALE		11			28	COMP_LO_LIM				4
11	OUT_RANGE		11			29	ARITH_TYPE				4
12	GRANT_DENY		2			30	BAL_TIME				4
13	INPUT_OPTS				2	31	BIAS				4
14	IN			5		32	GAIN				4
15	IN_LO			5		33	OUT_HI_LIM				4
16	IN_1			5		34	OUT_LO_LIM				4
17	IN_2			5		35	UPDATE_EVT				
18	IN_3			5		36	BLOCK_ALM				
Sub totals		23	26	48	7	37	BLOCK_ERR_DESC_1				
						From left column		23	26	48	7
						Totals		23	26	48	68

*This page intentionally left blank.*





# DIRECT SALES OFFICE LOCATIONS

## AUSTRALIA

Brisbane  
Phone: +61-7-3001-4319  
Fax: +61-7-3001-4399

Perth  
Phone: +61-8-6595-7018  
Fax: +61-8-6595-7299

Melbourne  
Phone: +61-3-8807-6002  
Fax: +61-3-8807-6577

## BELGIUM

Phone: +32-2-344-0970  
Fax: +32-2-344-1123

## BRAZIL

Phone: +55-11-2146-3600  
Fax: +55-11-2146-3610

## CHINA

Phone: +86-10-8486-4515  
Fax: +86-10-8486-5305

## FRANCE

Courbevoie  
Phone: +33-1-4904-9000  
Fax: +33-1-4904-9010

## GERMANY

Ratingen  
Phone: +49-2102-108-0  
Fax: +49-2102-108-111

## INDIA

Mumbai  
Phone: +91-22-8354790  
Fax: +91-22-8354791

New Delhi  
Phone: +91-11-2-6164175  
Fax: +91-11-5-1659635

## ITALY

Phone: +39-081-7892-111  
Fax: +39-081-7892-208

## JAPAN

Chiba  
Phone: +81-43-297-9222  
Fax: +81-43-299-1115

## KOREA

Phone: +82-2-2274-0748  
Fax: +82-2-2274-0794

## MALAYSIA

Phone: +60-3-2161-0322  
Fax: +60-3-2163-6312

## MEXICO

Phone: +52-5-310-9863  
Fax: +52-5-310-5584

## THE NETHERLANDS

Phone: +0031-15-3808666  
Fax: +0031-18-1641438

## RUSSIA

Veliky Novgorod  
Phone: +7-8162-55-7898  
Fax: +7-8162-55-7921

Moscow  
Phone: +7 495-585-1276  
Fax: +7 495-585-1279

## SAUDI ARABIA

Phone: +966-3-341-0278  
Fax: +966-3-341-7624

## SINGAPORE

Phone: +65-6861-6100  
Fax: +65-6861-7172

## SOUTH AFRICA

Phone: +27-11-452-1550  
Fax: +27-11-452-6542

## SOUTH & CENTRAL AMERICA AND THE CARIBBEAN

Phone: +55-12-2134-1201  
Fax: +55-12-2134-1238

## SPAIN

Phone: +34-93-652-6430  
Fax: +34-93-652-6444

## UNITED ARAB EMIRATES

Phone: +971-4-8991-777  
Fax: +971-4-8991-778

## UNITED KINGDOM

Wooburn Green  
Phone: +44-1628-536300  
Fax: +44-1628-536319

## UNITED STATES

Massachusetts  
Phone: +1-508-586-4600  
Fax: +1-508-427-8971

Corpus Christi, Texas  
Phone: +1-361-881-8182  
Fax: +1-361-881-8246

Deer Park, Texas  
Phone: +1-281-884-1000  
Fax: +1-281-884-1010

Houston, Texas  
Phone: +1-281-671-1640  
Fax: +1-281-671-1735

\* Masoneilan, SVI, and ValVue are registered trademarks of the General Electric Company. FOUNDATION Fieldbus is a trademark of the FOUNDATION Fieldbus organization. Other company names and product names used in this document are the registered trademarks or trademarks of their respective owners.



© 2014 General Electric Company. All rights reserved.

GEA31248B 05/2014