

1. General information

The instrument described in this manual has been designed and produced in conformity to the following standards:

EN 837-1-2 ed alla ASME B40.1. All components are submitted to severe quality and traceability controls. The quality management system is certified according to the ISO 9001 standard. This manual contains important information about the use and the installation of the gauge in safe conditions. Therefore it is highly recommended to read carefully the following instructions before using the instrument.

The instrument works in safe conditions when correctly selected and installed in the system and when the rules concerning the product as well as the maintenance procedures established by the manufacturer are respected.

The staff charged with the selection, installation and maintenance of the instrument must be able to recognize the conditions that may negatively affect the instrument's ability to work and which may lead to premature breakage. The staff must therefore be technically qualified and properly trained, and must carry out the procedures called for in the plant regulations.

Standards

- Directive P.E.D. 2014/68/EU

Nuova Fima instruments are designed and manufactured according to the safety rules included in the safety international standards in force. According to the 2014/68/EU standard the NUOVA FIMA pressure gauges are classified in 2 categories

PS <1000 bar these instruments should not satisfy the essential safety standards but they have only to be designed and manufactured according to a SEP-Sound Engineering Practice and they do not have to bring any CE marking.

PS >1000 bar these instruments should satisfy the essential safety standards established by the PED, they are classified as category I and they are certified according to Form A. They should bring the CE marking as reproduced below.



1.1 Intended use



These instrument are designed for Sanitary, Food Process and Pharmaceutical Industries in compliance with standard n° 74-06 of 3-A.

The absence of interstices and the mirror finishing of the components assure the best hygiene.

To reduce the effects of severe operating conditions like vibrations and pulsation, the instrument can be liquid filled

2. Installazione



Before installation be sure that the right instrument has been selected following the working conditions and in particular the range, the working temperature and the compatibility between the material used and the process fluid.



This manual does not concern the instruments conforming to standard 2014/34/EU (ATEX).



The product warranty is no longer valid in case of non-authorized modifications and of wrong use of the product.



The manufacturer disclaims all responsibility in case of damages caused by the improper use of the product and by the non-respect of the instructions reported in this manual.



The user is totally responsible for the instrument installation and maintenance.



Disconnect the instruments only after depressurization of the system.



The process fluids residuals in the disassembled gauges could affect people, the environment and the system. It is highly recommended to take proper precautions.

In order to verify the working and manufacturing features of the instruments read the catalogue sheets in the most up-dated edition available on-line on www.nuovafima.com

The instrument installation should be carried out according to standard EN 837-2 (Recommendation for pressure gauges installation and selection)

- Remove the diaphragm protection just before mounting treating it with extreme care. Scratches on the diaphragm are the main risk of chemical corrosion while crashing pressure on the concentric waviness affect the correct system operation.

- A chemical compatibility check between the process medium and the wetted parts is requested before installation. A description about the instrument material is marked by laser on the upper and lower body of the instrument as well as on the seal label.

- It is recommended to select approved seals for food treatment. The quick connection components such as clamps, pulleys, flanges and nuts are not included in the supply and they are not described in this manual.

- Instruments with the DIN 11851 connection must be installed using special gaskets type SKS.

- Instruments with process connection conformed to ISO 2853 (IDS/ISS) must be installed using those gaskets with supporting ring as described in the above mentioned directive.

- In case of fluids leakage during mounting, clean carefully.

- As for gauges with security device installation should guarantee a free space on the back side of 20mm at least.

- In order to guarantee the accuracy in measuring it is necessary to respect the working limits described in the catalogue sheets.

- Instruments should be installed in vibrations proof positions. If the mounting point is not stable because of vibrations a support for the instrument fixing should be used such as a clamp or a flange, possibly use a flexible capillary.

- If vibrations cannot be prevented during installation, use liquid filled instruments.

- The instrument mounting according to standard EN 837-1/9.6.7 established the vertical position as standard mounting. Calibration and therefore mounting positions different from standard (when requested) are shown on the dial.

- Instruments must be protected from wide ambient temperature variations.

- Instruments must be protected from sun radiations during working in order to prevent overheating.

- Liquid filled instruments used in temperatures lower than 20°C, could have higher response times because of the increase of viscosity of the filling liquid.

- During installation be sure that no deviation above or below the fluid allowed and the ambient temperatures takes place considering the heating radiations. It is necessary to consider the temperature influence on the accuracy value.

- During the first operating procedure all pressure rush should be prevented. Slowly open the interception valves.

- The use of instruments measuring the zero values is not recommended especially in gauges where the first part of the scale is suppressed.

- It is not recommended to reinstall the instruments on plants working with different process fluids in order to prevent any chemical reaction which could cause explosions owing to contamination of the wetted parts.

- If the pressure indication stays fixed for a long time be sure that this is not due to a closing up of the pipe

bringing the pressure to the sensing element. Before disassembling especially in case of pressure with zero value be sure that there is no pressure inside the gauge isolating it through the interception valve.

3. Use limits

3.1 Process and ambient temperature

This standard type instrument is designed to be used in safety conditions that is in an ambient temperature between -20 and +65°C. As for the filled model please see the paragraph "DAMPENING LIQUID FILLING". In case of temperatures below 0°C, it is recommended to use liquid filled gauges preventing that the components such as the measuring system toothing can freeze. The fluid must not freeze or crystallize inside the sensing element.

3.2 Working pressure

The instrument should be chosen considering the scale range which should be between 25% and 75% of the full scale range. The full scale range should be approximately double than the working pressure value.

3.3 Dynamic and cyclic pressures

The dynamic and cyclic pressures are normally indicated by the measuring index oscillations. They reduce the sensing element's and the amplifying movement's life. It is necessary to reduce the pulsating pressures placing a damper or a reducing valve between the pressure source and the instrument. The harmful effect of the pulsations could also be reduced filling the case with a dampening liquid. An improper choice of the instrument can bring to a breakage by stress.

3.4 Overpressure

Not applicable

3.5 Vibration

Vibrations can be detected through continuous and often irregular oscillations of the index or of the case... When the instrument is under vibrations it is recommended to use liquid filled pressure gauges.

3.6 Safety device

In systems working with compressed gas it is recommended to choose an instrument with a proper safety device in accordance to standard EN 837-2. In case of unexpected breaking of the sensing element the compressed gas expands outside the case through the safety device.

3.7 Dampening liquid filling

The dampening liquid is generally used to reduce vibrations of the moving parts due to vibrations and/or pulsations. It reduces considerably the use of the rotating parts increasing the instrument resistance to stress, increasing the instrument readability and it reduces the sudden loss of pressure.

The dampening liquid type should also be chosen considering the working temperature, the liquid viscosity degree and the expected damping level. As for working temperatures of the liquid filled instruments please see the instrument's catalogue sheet.

3.8 Protection in explosive ambient

In case pressure gauges are used in potentially explosive atmospheres special procedures are requested. The directive regarding the ATEX products 2014/34/EU is applied to pressure gauges with electrical devices as well as to mechanical pressure gauges.

In order to chose the products requiring these features please see the catalogue sheet and the manual.

4. Wrong use

4.1 Fatigue rupture

A continuous pressure variation highlighted by oscillations of indication can reduce the elastic element's life.

This breakage, which could be more dangerous if occur in measuring compressed gas instead of liquids, cause a pressure increase inside the case and therefore the safety device opening. In case of operation with high pressure the breakage could degenerate in an explosion. It is recommended to use dampening liquid filled instruments and to narrow the pressure entrance

conduit through a restrictor screw or an adjustable dampener.

4.2 Vibration and shocks rupture

Vibrations most commonly cause an abnormal deterioration of the parts in movement bringing to a gradual loss of accuracy and then to a total block of the pointer.

Vibrations could also cause stress cracks in the sensing element structure causing a liquid leakage and even an explosion.

5. Maintenance

The instrument's characteristics should be maintained during time through a special maintenance program which should be carried out and managed by qualified technicians.

All diaphragm seals are assembled and fixed to the instrument through a seal label. If this label or the assembling are altered improperly the whole system working and the relevant guarantee are affected.



ATTENTION: Do not remove or slack the filling valve and do not separate the instrument from the diaphragm seal. In case of leakage the assembling is not working anymore and must be returned in order to proceed to a separating circuit refilling.

The maintenance program includes: the cleaning of the external parts of the instrument by a humid cloth, the pressure indication check, the gaskets tightness check, condensate presence inside the case, the glass, case and safety device soundness.

As for heavy work instruments operating in severe conditions plants (vibrations, pulsating pressures, corrosive or sedimentous fluids, fuel or inflammable fluids) we recommend to schedule their replacement according to the maintenance program schedule. In case the instrument does not work properly it is necessary to proceed to an unschedule checking procedure.

Instruments should be kept in their original packaging and placed indoor and protected from humidity. The stocking area temperature should be between -25... and +65°C except different instructions.

A careless moving of the instrument could affect the metrological features although it is properly packed. Instruments should be checked before use. In particular in the zero free instruments it could occur that the null-pressure pointer position is inside the zero span.

5.1 Routine check

In order to verify the sensing element condition install the instrument on the pressure generator introducing an interception valve between them. Apply the maximum pressure value to the gauge and exclude it form the pressure source through the valve. Any possible leakage of the sensing element can be noticed from the slow return of the pointer to zero.

5.2 Ricalibration

If after recalibration results are different from the nominal values declared on the catalogue sheet the recalibration procedure should be repeated. It is recommended to return the instrument to NUOVA FIMA for this procedure.

NUOVA FIMA will not be responsible for any non authorized intervention on the instrument. Moreover the contract warranty and the CE Conformity Declaration will be no longer valid.

6. Disposal

An inappropriate disposal can be dangerous for the environment. The instrument components and packing materials disposal must follow an eco-compatible procedure and must be in accordance to the national standards. The fluid remaining inside the instrument could be dangerous or toxic for the environment, for people and for equipments.